


Resson Technologies

The People that Always Committed to Quality, Technology & Innovation



RD-14G

**Digital Readout System
Operation Manual
(Grinder)**

Resson Technologies Co., Ltd.

Precautions

For your protection, please read these safety instructions completely before operating the appliance.

- Selection of mains voltage
The Digital readout unit is supplied for 100V~230V, 50Hz/60Hz, 20W max operation.
Instructions prior to activation of unit
 1. Please ensure that the voltage rating corresponds to the mains supply prior to activation.
 2. If this unit is to be operated via an autotransformer from mains supply of higher voltage, it must be ensured that the low end of the transformer is connected to the neutral wire of mains.

 - The mains connector may only be inserted into a socket with earthing contact. The protective effect should not be cancelled by an extension lead without an earthed conductor. Any interruption of the earthed conductor either inside or outside of the unit or disconnection of the earthed conductor can render the equipment potentially dangerous. Any intentional break is not permissible.

 - Please install the Linear Encoder finish after that switch on the Digital Readout Unit. If switches on Digital Readout Unit before install the Linear Encoder not finished yet. This may cause electronic parts burnt away of the Linear Encoder.

 - Do not use the instrument in an extremely hot or humid place.

 - Do not use the instrument near strong magnetic or magnetic field noise place. This is the main reason that causes instrument error working.

 - Wipe the Digital readout unit surface with a soft cloth to remove fingerprints, dust, etc.

 - Clean the Digital readout unit surface with a soft cloth slightly moistened with Neutral purger to remove serious dirt.

 - Do not use the organic solvent products such as oil, diesel fuel, kerosene, alcohol, etc clean the Digital readout unit.

 - Do not use the Air guns fanned Digital readout unit and Linear Encoder accessories to let grease, dust or bits get into the Digital readout unit. This may cause the system working unstable and malfunction.
-

RD-14G Specification :

Number of axes : 1、2

Resolution : 0.001mm

Display function : 8位 LED 發光管


Response speed : 60m (198.6feet)/min

Quantizing error : \pm count

Power source : AC100V~230V / 50~60Hz / 20VA

Temperature fange : Service:0~40°C / Storage:-20~70°C

Linear Encoter (Scales) Electrical connector :



D-sub 9 pins connector



PIN	SIGNALS
1	N/C
2	0V
3	N/C
4	Inner shield
5	N/C
6	A
7	5V
8	B
9	R

N/C : No Connection





DIN 7 pins connector



PIN	SIGNALS
1	0V
2	N/C
3	A
4	B
5	5V
6	R
7	Inner shield

N/C : No Connection


1 Basic Functions	1
2 REF Datum Memory	6
3 Non Linear error Compensation	10
4 RD-14G Setup Function	17



Set Display to Zero

Purpose : Set the current position for that axis to zero


Example : To set the current **X Axis** position to zero




Inch / Metric Display Conversion

Purpose : Switches between inch and metric display

Example 1 : Currently in **inch** display, to switch to **metric** display




Example 2 : Currently in **metric** display, to switch to **inch** display



Enter Dimensions

Purpose : Set the current position for that axis to an entered Dimension

Example : To set the current **X Axis** position to **45.800 mm**



ABS / INC Coordinates display switches


Purpose : **RD-14G** provides two sets of basic coordinate display, they are **ABS** (absolute) and **INC** (incremental) displays.

During machining operations, the operator can *store the work piece datum (zero position)* in **ABS** coordinate, then switch to **INC** coordinate to continue machining operations.


The operator is then free to zero the axes or preset any dimensions into any axis in **INC** coordinate for relative position machining. The work piece datum (work piece zero position) is still retained in **ABS** coordinate by the **RD-14G**.

Operator can then toggle between **ABS** (absolute) and **INC** (incremental) coordinates without losing the work piece datum (work piece zero position).

Example 1 : Currently in **ABS** display coordinate, to switch to **INC** display coordinate




Example 2 : Currently in **INC** display coordinate, to switch to **ABS** display coordinate




Purpose : Counter provide center find function by halving the current display coordinate, so that the zero point of the work piece is located at the center of the work piece.

Example : To set the **X** Axis zero point at the center of the work piece


Step 1 : Locate the edge finder at one end of the work piece, then zero the **X** Axis.




Step 2 : Locate the edge finder at the opposite end of the work piece.



Step 3 : Then half the display coordinate using center find function as per follows




Now the X Axis zero point (0.000) is located right at the X center of the work piece.




199 Subdatum memory

Purpose : The readout offer 199 subdatum memory function, it is offered as a supplement of ABS/INC coordinates. All subdatums are reference to the ABS coordinate (in offer word, all subdatums are independent to INC coordinate).

Example 1 : Currently in **INC** display, coordinate to switch to **Sdm** display coordinate



Example 2 : Currently in **Sdm 3** display coordinate, to switch directly to **Sdm 9** display coordinate




Vibration filtering


Purpose : High accuracy and high resolution (1u) display are essential for grinder application. However, under the high resolution display, the last digit display may keep toggling caused by the vibration of the Machine during the machining process, especially in large grinder.

The innovative vibration filtering function can filter the display toggles to obtain a more comfortable readings, and hence reduces human mistake.


Example 1 : The tum vibration filter on.



Example 2 : Vibration filter currently on, to turn it off



ref datum memory



function : During the daily machining process, it is very common that the machining cannot be completed within one working shift, and hence the DRO has to be switched off, or less commonly, a power failure occurs whilst machining which leads to loss of the work piece datum (work piece zero position). The re-establishment of work piece datum using edge finder or other method inevitably introduces machining inaccuracies, because it is not possible to re-establish the work piece datum exactly at the previous position.


To allow the recovery of work piece datum very accurately, with no need to re-establish the work piece datum using an edge finder or other methods, every transducer has a reference point location to provide a datum point memory function.

The working principal of the ref datum memory function is as follows.

- There are a permanent and fixed mark (position) on the transducer, normally called **ref** mark or **ref** point..

Since this **ref** point position is permanent and fixed, it will never change or disappear when the DRO system is switched off. Therefore, we simply need to store the distance between the **ref** point and the work piece datum (zero position) in DRO's memory. Then, in case of the power failure or the RD-14G being switched off, we can recover the work piece datum (zero position) by presetting the display zero position as the stored distance from the **ref** point.

Example : to store the X axis work datum



Operation : RD-14G provides one of the most easy-to-use **ref** datum memory function.


There is no need to store the relative distance between the **ref** mark and your work datum zero into the RD-14G, whenever you alter the zero position of ABS coordinate, such as by zeroing, centre find, coordinate preset or etc., RD-14G will automatically store the relative distance between ABS zero and the **ref** mark location into RD-14G's memory.

In daily operation, operator simply needs to locate the **ref** mark position whenever they switch on the RD-14G to let it know where the **ref** mark position is, then RD-14G will automatically do the work datum storage on its' own . In the case of a power failure or the RD-14G being switched off, the operator can recover the work piece datum easily by using the **RECALL 0** procedure.


function : In ref datum memory function, the **RD-14G** will automatically store the relative distance between the *ref* mark position and the work piece datum (zero position) whenever the operator alter the **ABS** zero position, such as zeroing, centre find, co-ordinate preset or etc...

Therefore, the **RD-14G** needs to store the *ref* mark position prior to any machining operation. So that the loss of the work piece datum (zero position) is avoided during any accidental or unexpected events, such as power failure or etc.. it is recommend that the operator finds the *ref* mark position using the (**FIND REF**) function whenever he switches on the **RD-14G**.


step 1 : To enter the ref function, select the **FIND REF** (find *ref* mark)



step 2 : select the axis of which *ref* mark needs to be found




step 3 : move the machine reader head across the length of the transducer until digits display in **RD-14G** start to count.




Recall the work datum zero (RECALL 0)

function : If the ref point is lost for any reason, the work piece datum can be recovered by **RECALL 0** function as follows:.


step 1 : enter into the **ref** function, select the **RECALL 0** (recall work piece zero)





step 2 : select the axis of which work datum (zero position) needed to be recovered



step 3 : move the machine across the length of the transducer until the **RD-14G** display starts to count, then the work piece datum is recovered



Non Linear error compensation




Non Linear error compensation

The Grinder readout offers non-linear error compensation to improve readout accuracy to maximum possible limit.


Principle of Operation:


Non-linear error compensation make use of the REF (reference mark) position of the linear scale to locate the absolute position of the machine. The readout's CPU then compensate the readout readings according to the error table that built in during the set up process. The compensation always started vital important to have the CP.START position located at most negative position of the machine. Counter offers a maximum of 30 non-linear compensation steps, the linear compensations is effect between the compensation steps.




Operation procedure

1) Locate the REF zero at ABS coordinate:







Let's say take X as an example



move the machine across the ref mark of the scale until the digits display start run. **Please remember that to move the scale must be moved towards the positive direction.**



after the display digits start run, move the machine to $x=0.000$, it is the ref mark position.




2) Locate the CP.START position:

The CP. START position is the absolute reference for the internal error compensation calculation of the readout, it is the start point of the error curve, to make fast real time calculation possible, the readout assume all internal error compensation calculations are only in positive direction. Therefore, the CP. START position should be located in the most negative position of the machine, so that all measured position in the error curve are located in positive position.

I.e. In the example below, we are using a step gage which have total measurement travel of 300mm as our measurement standard. The step pitch of the step gage is 25mm
Our maximum machine travel is 265mm. Therefore,


CP. PITCH = 25mm

CP. STEP = $(265/25) = 10.6$ steps, since steps must be in integer, then round up to = 10steps




Non Linear error compensation

Using a dial indicator to locate the most negative position of the step gage, zero the dial indicator at that position, record down this position as the CP. START position.




Because the CP. START position always in the most negative position of the machine, therefore, it should always be negative value.




Please record down this position by pen, in this example, the CP.START position = -115.875

3) START measure the error, to build up a error curve.



To mark the error measurement more easy, swap to INC coordinate and zero at the CP. START position.




swap to INC coordinate



zero at the CP. START position in INC coordinate



Start measure the error by positioning the dial indicator on the step gage. Take down the display value shown at the readout.




- Record down the measured value from the readout and fill up following table

Standard position	Measured value
25.000	25.008
50.000	50.004
75.000	75.017
100.000	99.995
125.000	125.002
150.000	150.012
175.000	174.997
200.000	199.988
225.000	225.007
250.000	250.015


CP.START = -115.875
 CP.PITCH = 25.000
 CP.STEP = 10

4) enter the error curve value into the readout

switch off the readout and them switch it on again




During the start up procedure, when the readout display the software version number, press "ent" once to enter the SET UP function




Non Linear error compensation


after entered the SET UP function of the readout, press "down" button until display "NL Error" appear.





NL Error is Non-Linear Error (Non Linear Error Compensation)



Press to enter into NL Error function






enter the CP.START






enter the CP.START

next step




enter the CP.STEP

next step




MEAS VAL is Measured Value




next step





Press to confirm the choice




after enter the MEAS VAL mode
press "up" or "down" button
to select the step point value



after all measured value
entered into the readout,
press "ent" to exit the
NL Error function



Press "down" key until
display shows "QUIT"




Press "ent" the quit
the SET UP function

* it is very important to remember to switch off the readout. The error curve data will be moved to the RAM memory of the readout only during the power star up procedure. Therefore, after entered the error curve data, the display must be switched off at least one time.




RD-14G
Digital Readout Setup Function



- DIRECTIN specifies the direction of count for each axis
- LIN COMP permits linear error compensation to be input
- NL Error permits non linear error compensation to be input (point compensation)
- FILTER permits the filter value to be set
- QUIT exits the SETUP function to proceed to normal working

RD-14G ORIGINAL PARAMETER RESET FUNCTION




Some inscrutable cases or improper operations cause the chaos of parameter, then you need to initialize the parameter to reset the system.


Operational procedure :

- (1) Turn off the DRO.
- (2) Power on DRO once again, when "VER.**" moving in display window, please press "8" key then DRO enters into the RESET function.

power on the DRO, then DRO starts the self-test function




when "VER.9GA" appears in display window, please press "8" key.




when some messages are displayed over, the DRO enters into the RESET function.

Digital Readout Setup Function


(3) When enter into the RESET function, DRO will display :



display "RAM TEST" that means the RAM is testing




if the RAM function is normal , DRO can display "RAM OK"




display "RESET" that means the parameter has reset

(4) The reset of parameter has completed then start to enter into the test procedure of display light.



(5) Turn off the DRO after complete the reset, then power on the DRO once again.


RD-14G SETUP FUNCTION



During changing the different program version IC or some abnormal voltages and operations, you need to SETUP the DRO.

Procedure :

- 1). Turn off the DRO.
- 2). Power on the DRO once again, when the message "VER.9GA" showing in the MESSAGE WINDOW, please Enter key immediately then the DRO starts entering into the SETUP function.






The SETUP procedure is written in a menu mode which enables you to scroll through the top level options and enter, configure and exit the sub-functions as they arise.


The top level menu headers in order are as follows :


- | | |
|----------|--|
| DIRECTIN | specifies the direction of count for each axis |
| LIN COMP | permits linear error compensation to be input |
| NL Error | permits non linear error compensation to be input (point compensation) |
| FILTER | permits the filter value to be set |
| QUIT | exits the SETUP function to proceed to normal working |



Digital Readout Setup Function


3.) Press  key to select the "DIRECTN" (counting direction) function. Press  key to return to the last function.






Press  key into the direction setting function, the 0 represents a positive, 1 represents a negative.




Press  or  key to set up a negative direction "1" for X Axis, make a same procedure for Y Axis.



4.) Press  key to make your setting, then press  key to select the "LIN COMP" (linear compensation) function.




Digital Readout Setup Function

Press  key into the linear error compensation function, the formula as below..
 error value X -(1000/measuring length) = compensation value
 (ML) measuring length unit = mm, error unit = μ m



Example..

$$\begin{aligned} \text{ML} &= 500\text{mm} & \text{Error} &= -15\mu\text{m} \\ -15\mu & \times -(1000/500) & &= 30\mu\text{m} \\ & & \text{the compensation value is} & 30\mu\text{m} \end{aligned}$$





If set up the linear compensation value of X Axis = 30, through the AXIS key make a same procedure for Y Axis.




5.) Press  key to make you setting, then press  key to select the "NL ERROR" (non-linear error compensation) function.



Digital Readout Setup Function






6.) Press key to select the "FILTER" function.





Digital Readout Setup Function


Press  key into the digital filter setting function, then you can increase digital value until the digital does not pulsate. Please note that the value of DE (digital filter) is larger means the integrate is larger then the display is more stable.



7.) Press  key to make your setting, then press  key to select the "QUIT" function.



Press  key to make your selection, then the DRO will exit the SETUP function and return to the "ABS" state.



By pressing the ENTER key the DRO exits the SETUP program and is ready for machining operations. If use the error compensation function, you must turn off the DRO then power on the DRO again, otherwise your compensated value will invalid.